

CONVERSION TABLE: SQUARE METER
TO SQUARE FEET IN AREA

By: Guam Housing and Urban Renewal Authority

CONVERSION TABLE

Square Meter to Square Feet in Area

Factor 10.76391 = 1 Square Foot

<u>Sq. Meters</u>	<u>Sq. Feet</u>	<u>Sq. Meters</u>	<u>Sq. Feet</u>	<u>Sq. Meters</u>	<u>Sq. Feet</u>	<u>Sq. Meters</u>	<u>Sq. Feet</u>
1	10.76391	31	333.68121	61	656.59851	91	979.51581
2	21.52782	32	344.44512	62	667.36242	92	990.27972
3	32.29173	33	355.20903	63	678.12633	93	1001.04363
4	43.05564	34	365.97294	64	688.89024	94	1011.80754
5	53.81955	35	376.73685	65	699.65415	95	1022.57145
6	64.58346	36	387.50076	66	710.41806	96	1033.33536
7	75.34737	37	398.26467	67	721.18197	97	1044.09927
8	86.11128	38	409.02858	68	731.94588	98	1054.86318
9	96.87519	39	419.79249	69	742.70979	99	1065.62709
10	107.63910	40	430.55640	70	753.47370	100	1076.39100
11	118.40301	41	441.32031	71	764.23761	200	2152.78200
12	129.16692	42	452.08422	72	775.00152	300	3229.17300
13	139.93083	43	462.84813	73	785.76543	400	4305.56400
14	150.69474	44	473.61204	74	796.52934	500	5381.95500
15	161.45865	45	484.37595	75	807.29325	600	6458.34600
16	172.22256	46	495.13986	76	818.05716	700	7534.73700
17	182.98647	47	505.90377	77	828.82107	800	8611.12800
18	193.75038	48	516.66768	78	839.58498	900	9687.51900
19	204.51429	49	527.43159	79	850.34889	1000	10763.91000
20	215.27820	50	538.19550	80	861.11280		
21	226.04211	51	548.95941	81	871.87671		
22	236.80602	52	559.72332	82	882.64062	1 ac.	43,560 s.f.
23	247.56993	53	570.48723	83	893.40453	1 ac.	4,046.8564 s.m.
24	258.33384	54	581.25114	84	904.16844	2.47 ac.	1 hectare
25	269.09775	55	592.01505	85	914.93235	1 hectare	10,000 s.m.
26	279.86166	56	602.77896	86	925.69626	1 s.m.	10.76391 s.f.
27	290.62557	57	613.54287	87	936.46017	1 m.	3.28084 ft.
28	301.38948	58	624.30678	88	947.22408	1 ft.	0.3048 m.
29	312.15339	59	635.07069	89	957.98799		
30	322.91730	60	645.83460	90	968.75190		

Courtesy of Guam Housing
and Urban Renewal Authority